



#99- XP Magic Cut™

- Next Generation
- 2-Step Compound & Polish
- Our Fastest Cutting Product
- Rapidly Removes 1500 Sandpaper Marks and Paint Imperfections
- Easy to Use – Wool or Foam Pads
- Produces Almost No Swirls
- Rich Color Depth
- High Gloss and Reflection
- Quick Cleanup
- VOC Compliant
- Body Shop Safe

Description:

XP Magic Cut™ is an advanced 2-step compound and polish that works remarkably fast on all types of cured and fresh paint. The micron-sized abrasives level paint imperfections quickly with little effort and little swirl. It rapidly removes 1500 sandpaper marks, scratches, acid rain, oxidation, and other paint imperfections. This versatile system corrects paint while producing rich color depth, high gloss and reflection. Clean up is fast and easy. VOC compliant and body shop safe.

New Technology:

XP Magic Cut™ is formulated with advanced aluminum oxide abrasives. These micro-fine abrasive particles are much smaller in size compared to typical silica abrasive particles. The result is extra-fast and uniform cutting capabilities. Additionally, the aluminum oxide abrasives work “cooler” than most other abrasives; keeping the surfaces from getting overly hot while buffing.

Aluminium oxide's **hardness and strength** makes it suitable for use as an excellent abrasive in XP Magic Cut™ and as an important component in many high-end cutting tools. Most pre-finished wood flooring now uses aluminium oxide as a hard protective coating. With XP Magic Cut™ compound, the aluminum oxide abrasives cut faster and better because of their chemical composition. **Think of using diamonds to cut, opposed to cutting with rocks.**

Directions for best results:

Preparation:

Step 1: Thoroughly wash and dry the vehicle.

Step 2: Clay the painted surfaces with Clay Magic® detailing clay and 49-Body Shine®.

For wool or foam pad compounding:

Step 1: Apply a thin line of #99 XP Magic Cut™ to the paint surface. Spread compound onto panel with the pad before starting the machine. Use a white wool or medium to heavy cut foam pad.

Step 2: Begin compounding at 1400-1750 rpm. Buff until surface imperfections have been removed. Keep the pad “wet” by spraying a mist of #49-Body Shine® onto the buffed area. Add more XP Magic Cut™ if necessary to completely remove the marks.

Step 3: Wipe carefully with a clean, soft microfiber cloth.

Helpful Tips:

- Make sure the vehicle is washed and clayed prior to buffing.
- Buff while keeping the pad flat. This will help to reduce adding swirls to the paint.
- Keep the pad clean often using a pad spur tool.
- Follow compounding with a light-duty Auto Magic® wax or polymer to add more gloss and protection.

Suitable Applications:

- For use on all modern refinish paint systems: medium solids & high solids (fresh – cured).
- Recommended for use at PDI (pre-delivery inspection) centers.

Manufactured by:

Auto Wax, an ITW Company
1275 Round Table Drive
Dallas, Texas 75247
800-826-0828 / 214-631-4000
AutoWaxCompany.com

Auto Magic
Reconditioning Professional's #1 Choice®